

Ultrascale Data Sheet

Issue: 001-060830

Bachmann Class 20



Fitting Instructions:

The Bachmann class 20 conversion pack comes as a fully assembled set of wheels, axles, bushes and gears. (*as shown above*)

All the modeller needs to do is remove the base plate from each bogie, take out the original Bachmann wheel sets and fit the new Ultrascale conversion pack wheels. The wiper pick-ups will need to be adjusted to suit the wider E.M. and 18.83 gauges, but this is made easier than previous conversions as we have used our new design of wheel for this conversion which has a completely enclosed metal back. (see inset image above) This means that the pick-ups can touch anywhere on the back of the wheel and still make electrical contact. Once the wheels have been fitted and the bogie bases replaced the model is ready for use.